

Huion Graphics Tablet

Graphics Tablets are devices created to simulate the feel and technique of drawing with pen and paper on the computer. Any action done with the digital pen on the tablet is mirrored on the computer, allowing the user to draw or write as if they were drawing on paper and see it on screen. The Huion HPro610 is one of these tablets that also includes customizable hotkey buttons on the side to add more functionality, along with customizable buttons on the stylus and pressure sensitivity.

Set-Up

On the left side of the Graphics Tablet (the side with the buttons), find the Mini-USB port and plug it in.



Connect the USB cable to an open port on the Mac Computer




Take out the pen holder to store the stylus when not in use.




You're Ready to go! The tablet should work simply by being connected but if you would like to make use of the Hot Keys on the left-hand side or change the functionality of the stylus buttons/pressure sensitivity, go to the next step.



Change Settings










To change the Pressure Sensitivity, move the slider to left to make it less sensitive or right for more sensitive.



Clicking Advance Settings button and it will bring you to the Workarea and Hotkeys Settings.





To switch the tablet to Left-Handed mode, check of the Left Hand option on the right side. SoftKey Enable SoftKey Disable Full Area Screen Ratio Disable ExpressKey Left Hand To change the Hotkeys, first click on the Favorites hotkey you want to change. (AirDrop All My Fil K1 iCloud Di Applicati K2 ___ Desktop кз Documer Download audiowor Devices K5 Remote [Then on the bottom right where it says Keyboard Key, you can change which Full Area keyboard keys it's mapped to. Check the Screen Ratio program you want to use to get the correct Disable ExpressKey keyboard shortcuts. (For example, for a Left Hand program that has Undo mapped to Command + Shift + Z, select Z first)



After, you can select which other keys need to be pressed. For the previous undo Disable Expresskey example, you would select command. More Left Hand than one key can be selected, for example if Keyboard Key you wanted to add Shift + Command + Z, Z you would need to check both Command and Shift. Control Option Command Now pressing the 3rd hotkey will simulate Shift pressing Command+Shift+Z.

Charging the Pen

The pen is charged using a special cable with one USB end and an end similar to a screw



Attach the USB end to the computer or a USB charger and the other end into the top of the pen



A red light should appear under the two pen buttons.



Once the pen is fully charged the light will disappear.






Replacing the Pen Nib


You can twist off the top of the pen holder by turning it counter clockwise.



Holding the top part of the pen holder in one hand, use the other hand to put the pen into the hole on the bottom.



Tip the pen to get the old nib out





Take a new nib from the bottom half of the pen holder.



Push the new nib into the pen until its firmly in. Put the pen holder back together.



Additional Resources

Huion h610Pro Product Page with Manual Download: https://www.huiontablet.com/huion-h610pro.html

Tablet Review that Discusses the Settings Windows at 2m46s https://youtu.be/cuUsQcPwCZo?t=2m46s

